

*penreco*®

**Versagel® ML 750**  
*Be... Contoured*

A soft melting gel balm  
to sculpt and shape the body

## Be... Contoured

### PRODUCTS

Raw Material	Composition	% w/w	Supplier
<b>PHASE A</b>			
Temest 810	Caprylic/Capric Triglycerides	81.50	Temix Oleo
Rheopearl HC	Dextrin Palmitate	5.00	Miyoshi Kasei
Versagel ML 750	C12-15 Alkyl Benzoate, Ethylene/Propylene/Styrene Copolymer, Butylene/Ethylene/Sytrene Copolymer, BHT	10.00	Penreco
Lexgard O	Caprylyl Glycol	1.00	Inolex
<b>PHASE B</b>			
Ronacare Poppy SE	Caprylic/ Capric Triglyceride, Papaver Rhoas Extract, Tocopherol	1.00	Merck
Colorona Oriental Beige	Mica, C.I.77891, C.I.77491	0.50	Merck
Citrus Fruits 127	Perfume	1.00	IFF

### MIXING INSTRUCTIONS

Heat phase A to 85°C and mix until homogenous. Add phase B to phase A.  
Mix until homogenous and pour into suitable containers.