

penreco®

Versagel® MD 500 T
for Eye

A priming base to use alone or
before the application of eye color

Eye Primer

PRODUCTS

Raw Material	Composition	% w/w	Supplier
PHASE A			
PLUROL DIISOSTEARIQUE CG	Polyglyceryl-3 Diosostearate	3.50	Gattefosse
VERSAGEL MD 500 T	Isododecane, Ethylene/Propylene/Styrene Copolymer, Butylene/Ethylene/Styrene Copolymer, Pentaerythrityl Tetra-di-t-butyl Hydroxyhydrocinnamate	20.00	Penreco
PHASE B			
DEIONISED WATER	Aqua	73.30	
PARATEXIN SBG	Sodium Benzoate	0.20	Azelis
SODIUM CHLORIDE	Sodium Chloride	1.00	
PHASE C			
POWDER LA VIE	Mica, Hydroxyapatite, Zinc Oxide	2.00	Miyoshi Kasei

MIXING INSTRUCTIONS

Premix phase A.

Premix phase B.

Add phase B to phase A slowly with mixing.

Switch to high shear mixing for 1 minute.

Add phase C mixing until homogenous.